



Steering Column Adaptor Installation Instructions



(Instructions are for any of our 5,6,or 9 bolt Adaptors)

1. Remove old steering wheel and horn assembly.
2. Remove dust cover by removing 3 screws if dust cover is steel. If dust cover is plastic pry it off. Discard the cover, you will not need it.
3. Install ididit adaptor by aligning the horn cam and center splined shaft protruding from steering column. Replace nut and tighten to 40 ft. lbs. Occasionally because of the minimum clearance, and adaptor will rub on your column. If this is the case with your column simply remove the adaptor and wrap one turn of clear cellophane tape on the tapered area of the steering column just below the splined area. Sometimes it is necessary to wrap the taper area twice.
4. Install the steering wheel and the bolts that hold the wheel on. Remember to have the steering wheel straight.
5. Install horn wire. Horn wire fits through the adaptor into the horn cam. Turn 1/8th of a turn, clockwise. Push other end of the horn wire onto horn button. Push horn button on an angle into adaptor.
6. The installation is completed. If you have any further questions please call ididit!

Thank you for your adaptor purchase.