

Classic Chevy Floor Mount Installation Instructions

For Part #'s 2401400010, 2402400010



The Classic Chevy Floor Mount is made up of two pieces:

- A.) T-shaped L Bracket
- B.) Locking Clamp

Bolt the T-shaped L-bracket (A) (with the extension on the bottom) to the inside floor using the original bolt holes. The long extension will point towards the driver. Next, slide the locking clamp (B) up the tube of the steering column. Slide the steering column through the floor board. The column will sit above the extension. With the column in place, slide the clamp down over the extension of the floor bracket, securing it to the column. Tighten all fasteners when you are comfortable with the installation. Your column is now secured to the floor.

***PLEASE NOTE:** The enclosed floor mount has a "hot dip" black oxide finish. It would be important to put a permanent finish on it before you install this floor mount.



ididit inc. 610 S. Maumee St. 49286 Tecumseh, MI • PH: 517-424-0577 • FAX: 517-424-7293 • ididitinc.com

Instruction #: 8000010199 REV 08/15