

1967-68 Ford Mustang Steering Wheel Adapter Installation

For Part Number's 2203360030, 2203360040



IDIDIT'S line of Steering Wheel Adapters are designed to be bolted to Ford OEM or IDIDIT Ford-Style Topshaft 67-68 Mustang column. Installation should be done by a trained professional. Please read these instructions thoroughly before beginning installation efore beginning installation.

DISCLAIMER:

Because IDIDIT, LLC has no control over installation and/or use of its products, IDIDIT, LLC will not be held liable for personal, property, legal or financial damages or claims stemming from the use or misuse of any product we manufacture or sell. The purchaser assumes all risk and responsibility for safety, performance and applicability of these products.

INSTALLATION:

1. Assemble steering wheel to steering wheel adapter hub using nine (9) supplied bolts. Locate the adapter notch so that the cancellation pin is at the 9o'clock position. Loctite and torque to 10-12 in/ lbs. **DO NOT EXCEED.**
2. Make sure the collar is installed on adapter with the thicker portion away as shown in figure 1. And threaded as far as possible on adapter. Failure to do so will result in collar contacting steering column, preventing adapter from seating correctly on steering shaft, and possible damage to the column.

67-68 TURN SIGNAL SWITCH WITH HAZARD SWITCH AND 9-WIRES

Figure 1

